In the Santa Clara Valley, storm drains flow directly to our local creeks, and on to San Francisco Bay, with no treatment.

Storm water pollution is a serious problem for wildlife dependent on our waterways and for the people who live near polluted streams or baylands.

Proper management of construction sites reduces pollution significantly.

This sheet summarizes the "Best Management Practices" (BMPs) for storm water pollution prevention.

## ORDINANCE OF THE CITY OF CUPERTINO FOR STORM WATER POLLUTION PREVENTION & WATERCOURSE PROTECTION: Chapter 9.18

## 9.18.040 Discharge into the storm drain prohibited

It is unlawful to cause, allow, or permit to be discharged, any discharge not composed entirely of stormwater to the storm drain system or to surface waters or to any location where it would contact or eventually be transported to surface waters, including flood plain areas, unless specifically called out in the Municipal Regional Permit as an exempt or conditionally exempt discharge.

### 9.18.070 Accidental Discharge

All persons shall notify the Director of Public Works immediately upon accidentally discharging pollutants of concern to enable countermeasures to be taken by the City to minimize damage to storm drains and the receiving waters. Initial notification shall be followed, within five (5) business days of the date of occurrence, by a detailed written statement describing the causes of the accidental discharge and the measures being taken to prevent future occurrences. Such notification will not relieve persons of liability for violations of this chapter or for any fines imposed on the City on account thereof under Section 13350 of the California Water Code, or for violation of Section 5650 of the California Fish and Wildlife Code, or any other applicable provisions of State or Federal laws.

### 9.18.220 Violation\*

Any person who violates any provision of this Chapter shall be guilty of a misdemeanor and upon conviction thereof shall be punished as provided in Chapter 1.12 of the City of Cupertino Municipal Code.

Chapter 1.12: General Penalty, Section 1.12.010, paragraph D, states\*:

Unless otherwise specified by this code, an infraction is punishable by:

- A fine not to exceed \$100 for a first violation
- A fine not to exceed \$200 for a second violation A fine not to exceed \$500 for a third violation of
  - the same chapter within one year.

## 9.18.240 Civil penalty for illicit discharges\*

Any person who discharges pollutants, in violation of this Chapter, by the use of illicit connections shall be civilly liable to the City in a sum **not to exceed twenty-five thousand** dollars per day per violation for each day in which such

\*Excerpts – For complete CODE language refer to the City of Cupertino Municipal Code.

> **Building Dept:** 408-777-3228 Public Works Dept: 408-777-3354 Santa Clara County Recycling Hotline: 800-533-8414 www.reducewaste.org www.recyclestuff.com Small Business Hazardous Waste: 408-299-7300 Cupertino Sanitary Sewer Distr 408-253-7071 Santa Clara Valley Urban Runoff Pollution Prevention Prgm

800-794-2482 State Office of Emergency

Services 1-800-852-7550 (24 hrs)

Report spills to 911

DIRECTOR OF PUBLIC WORKS

## General Construction and Site Supervision

### Storm Drain Pollution from Construction Activities

Construction sites are common sources of storm water pollution. Materials and wastes that blow or wash into a storm drain, gutter, or street have a direct impact on local creeks and the Bay. As a contractor, or site supervisor, owner or operator of a site, you may be responsible for any environmental damage caused by your subcontractors or employees.

- ☐ Keep an orderly site and ensure good housekeeping practices are used.
- Maintain equipment properly. Cover materials when they are not in use.
- drains and drainage channels. Ensure dust control water doesn't leave site or discharge to storm drains.

Keep materials away from streets, storm

Advance Planning To Prevent Pollution Schedule ex cavation and grading activities for dry weather periods. To reduce soil erosion, plant temporary vegetation or place other erosion controls before rain begins. Use

the Erosion and Sediment Control Manual,

available from the Regional Water Quality

- Control Board, as a reference. Control the amount of runoff crossing your site (especially during excavation!) by using berns or temporary or permanent drainage ditches to divert water flow around the site Reduce stormwater runoff velocities by constructing temporary check dams or bems
- where appropriate Train your employees and subcontractors. The city can provide brochures about these issues for you to distribute to workers at your construction site. Inform your subcontra dors about the stomwater requirements and their own responsibilities. Use Blueprint for a Clear Bay, a construction best management ractices guide available at our Building Dept. counter.

## Good Housekeeping Practices

- Designate one area of the site for auto parking. vehicle refueling, and routine equipment maintenance. The designated area should be well away from streams or storm drain inlets, bermed if necessary. Make major repairs off site. To prevent off-site tracking of dirt, provide
- provide a tire wash area. ☐ Keep materials out of the rain – prevent runoff contamination at the source. Cover exposed piles of soil or construction materials with plastic sheeting or temporary roofs. Before it rains, sweep and remove materials from surfaces that drain to

entrances with stabilized aggregate surfaces. Or

- storm drains, creeks, or channels. Contain all litter, food wrappers, bottles and cans - Place lidded trash and recycling bins
- around the site. Clean up leaks, drips and other spills
- immediately so they do not contaminate soil or groundwater or leave residue on paved surfaces. Use dry cleanup methods whenever possible. If you must use water, use just enough to keep the
- dumpsters under roofs or cover with tarps or plastic sheeting secured around the outside of the dumpster. Never clean out a dumpster by hosing it down on the construction site.

Cover and maintain dumpsters. Place

- ☐ Place portable toilets away from storm drains. Make sure portable toilets are in good working order. Check frequently for leaks.
- Materials/Waste Handling ☐ Practice Source Reduction -- minimize waste when you order materials. Estimate carefully.
- Recycle excess materials, whenever possible. such as concrete, asphalt, scrap metal, solvents, degreasers, cleared vegetation, paper, rock, and vehicle maintenance materials such as used oil. antifreeze, batteries, and tires: www.reducewaste.org for info
- Dispose of all wastes properly. Materials that cannot be recycled must be taken to an appropriate landfill or disposed of as hazardous waste. Never bury waste materials or leave then in the street or near a creek or stream bed.
- In addition to local grading and building permits, you will need to obtain coverage under the State's General Construction Activity Stormwater Permit if your construction site's disturbed area totals 5 acres or more. Information on the General Permit can be obtained from the Regional Water Quality Control Board. (This criteria will change to one

## Landscaping, Gardening, and Pool Maintenance

## Lands caping/Garden Maintenance

- Protect stockpiles and landscaping materials from wind and rain by storing them under tarps or secured plastic sheeting.
- Schedule grading and excavation projects during dry weather
- Use temporary check dams or ditches to divert runoff away from storm drains.
- Protect storm drains with sandbags, gravelfilled bags, straw wattles, or other sediment
- Re-vegetation is an excellent form of erosion control for any site ☐ Store pesticides, fertilizers, and other
- chemicals indoors or in a shed or storage Use pesticides sparingly, according to instructions on the label. Rinse empty

containers, and use rinsewater as product

trash. Dispose of unused pesticides as

Dispose of rinsed, empty containers in the

In Cupertino, residents with curbside recycling can collect lawn, garden and tree trimmings in yardwaste toters. Yardwaste will be collected and composted by the city's contractors. Residents are encouraged to compost vardwaste on-site themselves. Or take

yard waste to a land fill where it will be

☐ Landscape contractors should take clippings and pruning waste to a landfill that composts yard waste (BFI's Newby Island and Zanker Rd. landfill are the nearest)

composted

Do not blow or rake leaves into the street

## Storm Drain Pollution from Landscaping and Swimming Pool Maintenance

Many landscaping activities expose soils and

increase the likelihood that earth and garden chemicals will run off into the storm drains during irrigation or when it rains. Swimming pool water containing chlorine and copper-based algaecides should never be discharged to storm drains. These chemicals are toxic to aquatic life.

## Pool/Fountain/Spa Maintenance

## Draining pools or spas

When it's time to drain a pool, spa, or fountain please be sure to call the Cupertino Sanitary District before you start for further guidance on flow rate restrictions, backflow prevention, and handling special cleaning waste (such as acid wash). Discharge flows should be kept to the low levels typically possible through a garden hose Higher flow rates may be prohibited by local ordinance.

- ☐ Never discharge pool or spa water to a street or storm drain; discharge to a sanitary sewer cleanout
- ☐ If possible, when emptying a pool or spa, let chlorine dissipate for a few days and then recycle/reuse water by draining it gradually onto a landscaped area.
- Do not use copper-based algaecides Control algae with chlorine or other alternatives, such as sodium bromide. Filter Cleaning
- ☐ Never clean a filter in the street or near a storm drain. Rinse cartridge and diatomaceous earth filters onto a dirt area. and spade filter residue into soil. Dispose of spent diatomaceous earth in the garbage.
- ☐ If there is no suitable dirt area, call Cupertino Sanitary for instructions on discharging filter backwash or rinsewater to the sanitary sewer.

## Earth-Moving **Activities**

### Storm Drain Pollution from Earth-Moving Activities

Soil excavation and grading operations loosen large amounts of soil that can flow or blow into storm crains when handled improperly. Sediments in runoff can clog storm drains, smother aquatic life, and destroy habitats in creeks and the Bay. Effective erosion control practices reduce the amount of runof crossing a site and slow the flow with check dams o roughened ground surfaces.

### Practices During Construction

- Remove existing vegetation only when absolutely necessary. Plant temporary vegetation for erosion control on slopes or where construction is not immediately planned.
- Protect downslope drainage courses, streams, and storm drains with wattles, or temporary drainage swales. Use check dams or ditches to divert runoff around excavations. Refer to the Regional Water Quality Control Board's Erosion and Sediment Control Field Manual for proper erosion and sediment control measures.
- ☐ Cover stockpiles and excavated soil with secured tarps or plastic sheeting.



## Dewatering Operations

## Storm Drain Pollution From Dewatering Activities

Be sure to call your city's storm water inspector at 408-472-9907 before discharging water to street, gutter, or storm drain. Filtration or diversion through a basin, tank, and sediment trap may be required. Reuse water for dust control, irrigation or another on-site purpose to the greatest extent

### Check for Sediment or Toxic Pollutants

- ☐ Check for odors, discoloration, or an oily sheen on ground water.
- Ask your city inspector whether the groundwater must be tested by a certified laboratory
- Depending on the test results, you may be allowed to discharge pumped groundwater to the storm drain OR you may be required to discharge to the sanitary sewer or collect and haul the water off-site for treatment and disposal at an appropriate treatment facility.
- ☐ When discharging to a storm drain, protect the inlet using a barrier of burlap bags filled with drain rock, or cover inlet with filter fabric anchored under the grate.
- ☐ Contact Cupertino Sanitary District at 253-7071 prior to discharging to the sanitary sewer.

The Project Contractor is responsible

located within the Public Right of Way

for removal of all BMP Facilities

upon project final inspection.

## Heavy Equipment Operation

Storm water Pollution from Heavy Equipment on Construction Sites Poorly maintained vehicles and heavy equipment that leak fuel, oil, antifreeze or other fluids on the construction site are common sources of storm drain pollution Prevent spills and leaks by isolating

equipment from runoff channels, and by

watching for leaks and other maintenance

problems. Remove construction equipment

### Site Planning and Preventive Vehicle Maintenance

from the site as soon as possible.

- ☐ Designate one area of the construction site, well away from streams or storm drain inlets, for auto and equipm ent parking, refueling, and routine vehicle and equipment maintenance. Contain the area with berms, sand bags, or other
- Maintain all vehicles and heavy equipment.
- Perform major maintenance, repair jobs, and vehicle and equipment washing off-site, where
- If you must drain and replace motoroil, radiator coolant, or other fluids on site, use drip pans or drop cloths to catch drips and spills. Collect all spent fluids, store in separate containers, and properly dispose as hazardous waste (recycle
- Do not use diesel oil to lubricate equipment parts, or clean equipment. Use only water for any onsite cleaning.
- O cover exposed fifth wheel hitches and other oily or greasy equipment during rain events.

## Spill Cleanup

### Clean up spills im mediately.

- ☐ Neverhose down "dirty" payement or im permeable surfaces where fluids have spilled Use dry cleanup methods (absorbent materials, cat litter, and/or rags) whenever possible and properly dispose of absorbent
- ☐ Sweep up spilled dry materials immediately. Never attempt to "wash them away" with water,
- Use as little water as possible for dust control. Ensure water used doesn't leave silt or
- ☐ Clean up spills on dirt areas by digging up and properly disposing of contaminated soil

☐ Call 911 for significant spills

☐ If the spill poses a significant hazard to hum an health and safety, property or the

State Office of Emergency Services.

The property owner and the contractor share ultimate responsibility for the activities that occur on a construction site. You may be held responsible for any environmental damage caused by your subcontractors or employees.

## Painting and Application of Solvents and Adhesives

## Storm Drain Pollution from Paints, Solvents, and Adhesives

All paints, solvents, and adhesives contain chemicals that are harmful to wildlife in local creeks, San Francisco Bay, and the Pacific Ocean. Toxic chemicals may come from liquid or solid products or from cleaning residues or rags. Paint material and wastes, adhesives and cleaning fluids should be recycled when possible, or disposed of properly to prevent these materials from flowing into storm drains and watercourses.

## Handling Paint Products

Keep all liquid paint products and wastes away from the gutter, street, and storm

## Painting Cleanup

- Never clean brushes or rinse paint containers into a street, gutter, storm drain, French drain, or creek.
- ☐ For water-based paints, paint out brushes to the extent possible, and rinse into an inside sink drain that goes to the sanitary sewer.

For oil-based paints, paint out brushes to the

extent possible and clean with thinner or

solvent. Filter and reuse thinners and solvents

where possible. Dispose of excess liquids and

residue as hazardous waste. ☐ When thoroughly dry, empty paint cans, used brushes, rags, and drop doths may be disposed of as garbage.

## Paint Removal

- ☐ Paint chips and dust from non-hazardous dry stripping and sand blasting may be swept up or collected in plastic drop cloths and
- disposed of as trash. ☐ Chemical paint stripping residue, and chips and dust from marine paints, or paints containing lead, mercury or tributyl tin must be disposed of as hazardous wastes. Lead based paint removal requires a state-certified contractor.
- ☐ When stripping or cleaning building exteriors with high-pressure water, block storm drains. Direct washwater onto a dirt area and spade into soil. Or, check with Cupertino Sanitary District to find out if you can mop or vacuum the washwater and dispose of it in a sanitary sewer drain. Sampling of the washwater may be required.
- Washwater from painted buildings constructed before 1978 can contain high amounts of Lead, even if paint chips are not present. Before you begin stripping paint or cleaning pre-1978 building exteriors with water under high pressure, test paint for lead by taking paint scrapings to a local laboratory. (See Yellow Pages for a state-certified
- ☐ If there is loose paint on the building, or if the paint tests positive for lead, block storm drains. Check with Cupertino Sanitary District to determine whether you may discharge water to the sanitary sewer, or if you must send it offsite for disposal as hazardous waste.

## Paint Disposal, Return or Donation

- ☐ Dispose of unwanted liquid paint, thinners. solvents, glues, and deaning fluids as hazardous waste (call the Small Business Hazardous Waste Prgm: 299-7300).
- ☐ Or Return to supplier. (Unopened cans of paint may be able to be returned. Check with the vendor regarding its "buy-back" policy.) ☐ Donate excess paint (call 299-7300 to donate.)

## Roadwork and Paving

- General Business Practices Develop and implement erosion/sediment
- control plans for roadway embankments. ☐ Schedule excavation and grading work during Check for and repair leaking equipment.
- Perform major equipment repairs at designated areas in your maintenance yard. where cleanup is easier. Avoid performing equipment repairs at construction sites.
- ☐ When refueling or when vehicle /e quipment maintenance must be done on site, designate a location away from storm drains and creeks.
- Do not use diesel oil to lubricate equipment parts or clean equipment. Recycle used oil, concrete, broken a sphalt,

## Asphalt/Concrete Removal

- Avoid creating excess dust when breaking asphalt or concrete.
- with rainfall or runoff.
- properly dispose of, all residues.

# Storm Drain Pollution

happen right in the street, where there are numerous opportunities for a sphalt, saw-cut slurry, or excavated material to illegally enter storm drains. Extra planning is required to store and dispose of materials properly and guard against pollution of storm drains, creeks, and the Bay.

## **During Construction**

- Avoid paving and seal coating in wet fresh materials from contacting stormwater
- when applying seal coat, slurry seal, fog seal, or similar materials. Protect drainage ways by using earth dikes,
- and filter runoff. ■ Never wash excess material from exposedaggregate concrete or similar treatments into a street or storm drain. Collect and recycle, or
- other construction materials with plastic tarps. Protect from rainfall and prevent runoff with temporary roofs or plastic sheets and berms

☐ Park paving machines over drip pans or

- absorbent material (cloth, rags, etc.) to catch drips when not in use. methods (with absorbent materials and/or rags), or dig up, remove, and properly dispose
- ☐ Collect and recycle or appropriately dispose of excess abrasive gravel or sand. ???

of contaminated soil.

## Fresh Concrete and Mortar Application -

## Storm Drain Pollution from Fresh Concrete and Mortar Applications

Fresh concrete and cement-related mortars that wash into lakes, streams, or estuaries are toxic to fish and the aquatic environment. Disposing of these materials to the storm drains or creeks can block storm drains, causes serious problems, and is prohibited by law.

- ☐ Wash out concrete mixers only in designated washout areas in your yard, away from storm into a temporary waste pit in a dirt area. Let water percolate through soil and dispose of settled, hardened concrete as garbage. Whenever possible, recycle washout by
- Wash out chutes onto dirt areas that do not flow to streets or drains.

under cover, protected from rainfall and runoff

Always store both dry and wet materials

- Protect dry materials from wind.
- concrete forms, tools, or trailers.

rainfall, and runoff.

## **During Construction**

- Don't mix up more fresh concrete or cement than you will use in a two-hour period.
- ☐ Set up and operate small mixers on tarps or heavy plastic drop cloths. ☐ When cleaning up after driveway or sidewalk construction, wash fines onto dirt areas, not
- down the drive way or into the street or storm ☐ Protect applications of fresh concrete and
- mortar from rainfall and runoff until the material has dried. Wash down exposed aggregate concrete only when the washwater can (1) flow onto a dirt area, (2) drain onto a bermed surface from which it can be pumped and disposed of properly, or (3) be vacuumed from a catchment created by blocking a storm drain inlet. If necessary, divert runoff with temporary berms.

Make sure run off does not reach gutters or

☐ When breaking up pavement, be sure to pick up all the pieces and dispose of properly. Recycle large chunks of broken concrete. See www.reducewaste.org for info on recyclers.

■ Never bury waste material. Dispose of small

storm drains, drainage ditches, or streams.

- amounts of excess dry concrete, grout, and mortar in the trash. ■ Never dispose of washout into the street,

## **Small Business Hazardous Waste**

Disposal Prgm Businesses that generate less than 27 gallons or 220 pounds of hazardous waste per month are eligible to use this program. Call 408-299-7300

for a quote.





SHEET:

SHEETS

### etc. whenever possible, or dispose of properly. (www.recyclestuff.com for list of recycling companies.) dispose to dirt area.

- After breaking up old pavement, be sure to remove all chunks and pieces. Make sure broken pavement does not come in contact
- ☐ When making saw cuts, use as little water as possible. Shovel or vacuum saw-cut slurry and remove from the site. Cover or protect storm drain inlets during saw-cutting. Sweep up, and

Sweep, never hose down streets to clean up

tracked dirt. Use a street sweeper or vacuum

truck. Do not dump vacuumed liquor in storm

Road paving, surfacing, and pavement removal

from Roadwork

- weather, or when rain is forecast, to prevent
- ☐ Cover and seal catch basins and manholes
- sand bags, or other controls to divert or trap
- ☐ Cover stockpiles (asphalt, sand, etc.) and
- ☐ Clean up all spills and leaks using "dry"
- Avoid over-application by water trucks for dust

- General Business Practices drains and waterways, where the water will flow
- pumping back into mixers for reuse.
- and away from storm drains or waterways. Secure bags of cement after they are open. Be sure to keep wind-blown cement powder away from streets, gutters, storm drains,
- Do not use diesel fuel as a lubricant on



**UPDATED SEPTEMBER 2016** 

CITY OF CUPERTINO

91/16 CONSTRUCTION BEST MANAGEMENT PRACTICES

DEPARTMENT OF PUBLIC WORKS